

1. For toilets that don't have a raised section at the bottom of the toilet bowl, put the insert into the grooves on the carriage.
2. For toilets that have a raised section at the bottom of the toilet bowl, remove the enclosed insert to allow for a tight fit.
3. Using the enclosed alcohol wipes clean around the entire area where the carriage and toilet meet. Be sure to remove any dirt.
4. With the TSK714 Toilet Support under the bowl unscrew the leg to tighten it snugly against the floor. Make sure the TSK714 Toilet Support is mounted straight and that it is centered under the toilet *Do not over tighten.*
5. Place a bead of adhesive on the top of the carriage and place the TSK714 Toilet Support in position under the toilet bowl.
6. Apply another bead of adhesive around the entire carriage where it meets the toilet. Be sure to fill in all gaps. Wipe off any excess adhesive with a damp cloth.
7. Allow 24 hours for the adhesive to set.
8. Once the adhesive has set the leg can be raised and lowered to clean underneath the TSK Toilet Support.

